



# Disassembling Logitech M305 Wireless mouse

This will allow you access to the internals of this mouse.

Written By: Darren



## Step 1 — Disassembling Logitech M305 Wireless mouse



- M305 Wireless mouse

## Step 2



- Turn mouse over to reveal the battery cover removal button.



### Step 3




- Slide the button back and then release in over to remove battery cover on the top of mouse.

### Step 4



- Remove small top access screw.

## Step 5




- Remove (gently) sticky pads with a small sharp knife or cutter.

## Step 6



- After removing all four sticky pads, unscrew the four screws. One screw for each hole.

## Step 7



- Once screws are removed, the top comes off, but be careful not to pull too hard because of the attached wires.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-18 12:02:19 AM.